


PRODUCT INFORMATION

How to extend the life of your Bottle Jacks

8 Top Tips


to extend the life of your TQB BRANDS Manual & Air/Manual Bottle Jacks

- 1 Ensure Hydraulic oil is at correct levels.




Remove Filter Plug and refill with SAE 32 grade Hydraulic Oil to the level indicated.

- 4 Never use bottle jack for supporting loads.



- 5 Use the available screw extension.




- 2 Regularly lubricate the Air motor and Manual Pump Pivots.

10ml SAE 32 grade Oil or Air Tool Lubricant.



Lubricate Pivots and Pins with 30/40W Machine Oil.

- 6 Always consult your vehicle manufacturer specifications for the correct lift point.



- 3 Always store in the fully lowered position.



- 7 Read the user's Manual thoroughly and keep a copy easily accessible.

- 8 Visit our webpage www.tqbbrands.com.au for instructional & pre-start video.